



ROOM TEMPERATURE SENSOR (for Automatic Air Conditioning System)

COMPONENTS



REMOVAL

1. REMOVE LOWER INSTRUMENT PANEL
- (a) Remove the lower instrument panel (see page IP-16).
2. REMOVE ROOM TEMPERATURE SENSOR
- (a) Disconnect the duct.
- (b) Disconnect the connector.
- (c) Detach the claws and remove the sensor.



INSPECTION


1. INSPECT ROOM TEMPERATURE SENSOR
- (a) Measure the resistance of the sensor.
- Standard resistance

Tester Connection	Condition	Specified Condition
1 - 2	10°C (50°F)	3.00 to 3.73 kΩ
1 - 2	15°C (59°F)	2.45 to 2.88 kΩ
1 - 2	20°C (68°F)	1.95 to 2.30 kΩ
1 - 2	25°C (77°F)	1.60 to 1.80 kΩ
1 - 2	30°C (86°F)	1.28 to 1.47 kΩ
1 - 2	35°C (95°F)	1.00 to 1.22 kΩ
1 - 2	40°C (104°F)	0.80 to 1.00 kΩ
1 - 2	45°C (113°F)	0.65 to 0.85 kΩ
1 - 2	50°C (122°F)	0.50 to 0.70 kΩ
1 - 2	55°C (131°F)	0.44 to 0.60 kΩ
1 - 2	60°C (140°F)	0.36 to 0.50 kΩ

- NOTICE:
- Touching the sensor even slightly may change the resistance value. Hold the connector of the sensor.

• When measuring the resistance, the sensor temperature must be the same as the ambient temperature.

HINT:
As the temperature increases, the resistance decreases (see the graph).
If the result is not as specified, replace the room temperature sensor.



INSTALLATION

1. INSTALL ROOM TEMPERATURE SENSOR

- (a) Attach the claws to install the sensor.
- (b) Connect the connector.
- (c) Connect the duct.

2. INSTALL LOWER INSTRUMENT PANEL

- (a) Install the lower instrument panel (see page [IP-23](#)).